


MESA TENIS DE MESA EXTERIOR SILOLI

Softtee®























REF: 0007147





MESA TENIS DE MESA EXTERIOR SILOLI

Softee®

REF: 0007147

 #1: Piano di gioco X 2	 #2: SUPPORTO GAMBE X 4	 #3: CONNESSIONE X 4	 #4: GAMBA X 2	 #5: PIATTINA RUOTE X 4	 #6: RUOTA X 4
 #7: CONNESSIONE GAMBE X 4	 #8: CONNESSIONE GAMBE X 4	 #9: PANNELLINO COPERTURA X 4	 #10: Rete X 1	 #11: Reggi-rete X 2	
	 #14: Bullone X 4	 #15: Bullone X 4	 #16: Bullone X 4	 #17: Bullone X 4	 #18: Bullone X 4
 #19: Rondella X 32	 #20: Rondella X 4	 #21: Gommone X 12	 #22: Dado X 16	 #23: Gommone X 8	 #24: Chiave X 2





* OJO! La tornillería no debe ser apretada en exceso.

MESA TENIS DE MESA EXTERIOR SILOLI

Softee®



REF: 0007147



MESA TENIS DE MESA EXTERIOR SILOLI

Softree®


REF: 0007147



MESA TENIS DE MESA EXTERIOR SILOLI

Softee®

REF: 0007147



MESA TENIS DE MESA EXTERIOR SILOLI

Softee®

REF: 0007147

